

Landis GYR LB1 Heating Junction Box

S U P P L Y	(L) 1
	(N) 2
	(E) 3
	4
	5
	6
	7
	8
	9
	10

Tank Thermostat			
(E)3	4	7	8
Yg	Br	Bl	Br

Boiler			
(L)1	(N)2	(E)3	

Pump			
(E)3	8		

Room Thermostat			
(L)1	(E)3	6	

LP522 Programmer				
(N)2	(L)1	4	5	7
Br	Bl	Br	Bl	Yg
Function		H/W Off	H/W On	C/H On

Programmer (Nest)				
(N)2	(L)1	4	5	7
Bl	Br	Bk	Gr	R

Diverter Valve				
(N)2	(E)3	6	7	8
Bl	G	W	Gr	Or

Disconnected